



## AMERICAN CAR CRAFT INSTRUCTIONS

### **C7 CORVETTE STINGRAY – FUEL RAIL COVERS FACTORY OVERLAYS POLISHEDW/BRUSHED TRIM**

**PART #053003**



#### **PARTS INCLUDED:**

- 2-Polished Fuel Rails**
- 2-Brushed Trim Rings**
- 2-Adhesive Promoter Packets**


**Liner info:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

1. The first thing that needs to be done in any peel and stick application is surface preparation. It is important that you examine the surface to determine if any kind of special treatments have ever been used. Such as wax/silicone treatments and/or polymer surface preps. Take a strip of masking tape and press it very firmly to make it adhere to the surface. Then peel it off to see how difficult it is to remove. If your masking tape is removed extremely easy and/or does not stick at all then you will need to perform a special surface preparation. In most cases like this you will need to make a solution of a straight detergent (Johnson's Baby Shampoo or Palmolive Dish Soap) and water. Mix a 32oz bottle with about five table spoons of soap detergent. Once you have the solution made wash the surface scrubbing quite vigorously to remove any surface contaminates.

When this is done you can proceed to the regular preparation. This is done by scrubbing the surface with alcohol and wiping it dry. At this point you will need to test the surface again to see if you have achieved a tack. Apply a new strip of masking tape to the surface. If it adheres you have done a good job, if it doesn't then you must perform the wash again and again if necessary until you have achieved a nice tack. Once a tack has

been achieved swipe the entire surface to be mounted with the adhesive promoter you will receive with any of our stainless steel kits. This promoter is not a cleaner but an adhesive accelerator when used on a nice clean and well prepared surface this chemical will create a very reliable bondable surface.

**2.** Now that all preparations have been made the next step will be to apply the accessory. It comes with a little brushed trim ring that's goes around the word corvette. You will need to place this on first. This will help with positioning the main fuel rail piece so that it is in the exact spot it needs to be mounted in. You can peel the red release liner from the back of the part. Keep in mind that the adhesive is very aggressive and it will not allow you to reposition it once it has made contact with the surface. So go slow and sure. Once all hole and the perimeters are lined up, set the part in place pressing firmly along the entire surface to bond the part and then remove the protective liner. The bond will become permanent after twenty-four hours.



If any questions or problems occur during installation, please contact American Car Craft at

**727-861-1500.**

**Thank You and Enjoy Your Purchase!**

**AMERICAN CAR CRAFT**

**18924 SAKERA RD HUDSON FL 34667**

**Phone: 727 861-1500      Fax: 727 861-1520**

**[www.americancarcraft.com](http://www.americancarcraft.com)**