



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO BRUSHED SIDE MARKER LIGHT BEZELS WITH BLACK OUTS

PART#102039 patent pending



PARTS INCLUDED:

- 4- Tinted black outs
- 4-Stainless Side Marker Bezels
- 1-Adhesive Promoter Tube

Your side marker bezels are designed to attach directly on the side marker lens.

1. Clean each side marker lens with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter provided
2. You have been provided with 4 black out vinyl's that match with all four side markers. Place these black out vinyls on your side marker using you thumb in a side to side motion. repeat steps...

3. Place each bezel into position to familiarize yourself with each placement before removing liner. VERY IMPORTANT: It will be necessary to hand form the bezels to conform to the shape of the car before installing; doing this will prevent any possibility of the bezel popping loose or lifting long term.
4. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each light. Press firmly to set.

DO NOT GET WET FOR 24 HOURS

**If any questions occur during installation, please contact American Car Craft at
727-861-1500.**

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**