



PARTS INCLUDED: 2-Stainless Side Marker Bezels 1-Adhesive Promoter Tube

Your side marker bezels are designed to attach directly on the side marker lens.

- 1. Clean each side marker lens with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter provided.
- 2. Place each bezel into position to familiarize yourself with each placement before removing liner. VERY IMPORTANT: It will be necessary to hand form the bezels to conform to the shape of the car before installing; doing this will prevent any possibility of the bezel popping loose or lifting long term.
- 3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each light. Press firmly to set.

## DO NOT GET WET FOR 24 HOURS!

IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CONTACT AMERICAN CAR CRAFT AT 727-861-1500 Thank You and Enjoy Your New Purchase!

> AMERICAN CAR CRAFT 18924 SAKERA ROAD-HUDSON FLORIDA 34667 Phone # 727-861-1500 Fax # 727-861-1520 www.americancarcraft.com