



AMERICAN CAR CRAFT INSTRUCTIONS

2005-2009 V6 & GT MUSTANG WATER TANK COVER

PART#273015 patent pending



PARTS INCLUDED:

- 1-Stainless Water Tank Cover
- 5-Velcro Attachment Cookies
- 1-Stainless Ring
- 1-Chrome Cap
- 1-Adhesive Promoter Pack

Your new cover comes to you with a protective liner. Do not remove liner until installation is complete.

1. Clean the entire top of the factory water tank and cap first with soap and water to remove any dirt and grime then scrub it with household rubbing alcohol until it is completely clean. Swipe the entire area you just cleaned with the adhesive promoter provided. NOTE: Save the pad for step 2.

2. You have been provided with five Velcro attachment cookies. Peel the release liner off of one side of these cookies and place them on all the high spots on the factory water tank and press firmly on them to set. Swipe the underside of your new stainless water tank cover with the adhesive promoter provided. Then pull the release liner off of the top half of all the cookies. Place your new cover into position and press firmly over the entire cover to make sure all of the cookies make contact.

3. You have been provided with a stainless ring which is designed to slip over the factory water tank cap. Note: On some production models the cap may contain extruded finger notches that will not allow the new ring to slip over properly or at all. If you have this particular cap simply sand the notches smooth with a bench grinder enough to allow the ring to slip over the factory cap. Once this has been accomplished remove the release liner from the underside of the chrome cap cover provided and place it over the factory water tank cap and press firmly to set.

4. Remove protective liner.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

**If any questions occur during installation please call American Car Craft at
727-861-1500.**

Thank you for your purchase!

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**