



## **AMERICAN CAR CRAFT INSTRUCTIONS**

---

### **HHR POLISHED WATER TANK COVER**

## **PART#423008**

#### **PARTS INCLUDED:**

- \_\_\_ 1-Stainless Water Tank Cover
- \_\_\_ 1-Decorative Chrome Cap w/attachment cookie
- \_\_\_ 1- Adhesive Promoter Pack
- \_\_\_ 1-120NC top hat cap w/putty

**You new cover comes to you with a clear protective liner. Do not remove liner until instructed.**

1. Completely remove the factory tank cap and the 10 mm bolt to the left of the tank.
2. Place the new cover over the tank and make any adjustments to the shape if needed to achieve a nice custom fitted cover.
3. Secure the new cover by replacing the factory nut. Remove the protective liner.
4. Trim off the finger tab and the o- ring strap completely from the factory cap. This can easily be done with a tin snip. Once this is done, re-install the cap to the tank.
5. You have been provided with a decorative chrome cap cover. To install, scrub the top of the factory cap with alcohol then swipe the cap once with the adhesive promoter provided. Remove the attachment cookie half from the under side of the decorative cover and attach it to the cap you just prepared. Then simply place the decorative cover over the factory cap to finish the installation.

**Note:** Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.



**If any questions occur during installation, please contact American Car Craft at  
727-861-1500.**

**Thank you and enjoy your new purchase!**

**AMERICAN CAR CRAFT**  
**18924 SAKERA ROAD-HUDSON FLORIDA 34667**  
**Phone # 727-861-1500 Fax # 727-861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**