



AMERICAN CAR CRAFT INSTRUCTIONS

HHR POLISHED WIPER COWL COVER

PART#423009

PARTS INCLUDED:

- ___1-Stainless Wiper Cowl Cover
- ___4-Zip Ties
- ___1-Adhesive Promoter Pack

You new cover comes to you with a clear protective liner. Do not remove liner until instructed.

Your new insert will set directly into the outlined curved section of the factory wiper cowl.

1. Remove the five harness retainers protruding through the top and face of the factory wiper cowl. Reattach this harness along the back of the engine to the other harness there with the four zip ties provided.

2. Scrub the top of the factory cowl with alcohol to remove dirt. Then swipe the area with the adhesive promoter provided. Before permanently installing, place the insert into position to check the fit and also to get acquainted with just how it will set in place. Once you have got a good idea about how you will set the insert simply remove the red release liner from the back of the cover and set in place. Press firmly along its length to set. Remove the protective liner.



If any questions occur during installation, please contact American Car Craft at 727-861-1500.

Thank you and enjoy your new purchase!

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com