



AMERICAN CAR CRAFT INSTRUCTIONS

2003-2010 VIPER SRT-10 Seat Sport Trim 2pc - Polished

Part # 971011



PART INCLUDED:

2-Sport Seat Trim with Viper Head Logo

1-Test Strip Tape

1-Tube Adhesive Promoter

Your part may come with a clear protective liner. If so, Do Not Remove until instructed to do so.

VERY IMPORTANT - PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING YOUR INSTALLATION! You must follow these instructions or your new part(s) may not adhere properly. If you remove the back red liner or scratch the surface of the trim it is not returnable.

- 1. BEFORE YOU BEGIN, YOU MUST FIRST PREP THE SURFACE IN ORDER TO ALLOW ADHESION.** You do this by scrubbing the entire area with household

Isopropyl Alcohol (or rubbing alcohol) found at most grocery stores and all hardware stores. Scrub the area vigorously to remove any dirt or oil.

2. Once properly cleaned take the piece of test strip tape included and remove a portion of the back red liner. Stick the test tape strip to the area where you will be mounting your new trim. Test several areas. If it is tacky and sticks then proceed to the next step. If it is not sticking very well in any of the spots you tested then re-clean the area until the test strip sticks to all areas.

3. Take your trim piece and without removing the back red liner - hold it up to where it is to be mounted. See how it fits. If the piece does not fit properly - STOP. Call us.

Become familiar with the way it fits into place. Now peel off the clear plastic top liner (if there is one).

4. Take the Adhesive Promoter Pen or packet and open it. Swab the area where you are going to mount your trim with the clear liquid. It will not stain or harm your car body or interior. It is designed to help the trim piece stick better to the surface. Let dry for 2-3 minutes.

5. Remove the red back liner and hold the trim piece slightly above where it is to be mounted. Do not touch it to the surface yet. Carefully maneuver the trim to the exact spot and gently set it into place without pressing on it. Make any final adjustments necessary. Repeat steps 1-5 for the other trim.

6. Now push along the entire surface starting in the center and working your way out. Keep the trim clean with a mild glass cleaner.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com