

INSTALLATION INSTRUCTIONS
37141 (1-2-3-4) SIDE BAR
JEEP WRANGLER 97-06 / JEEP UNLIMITED 05-06

Parts List:	(1) Hardware kit including:
QTY	(4) 1/2" x 2" Hex head bolt
(1) Sidebar set (Left & Right)	(8) 1/2" x 1" Hex head bolt
(1) Rear Mounting brackets set	(12) 1/2" Flat washer
(1) Front Mounting brackets set	(12) 1/2" Lock washer
(4) Mount plate	

Tools required:
 3/4" Socket Ratchet
 3/4" Wrench


Aproximated installation time: 30 min.

Instructions:

1. Read and understand instructions completely before beginning installation.
2. Sidebar set consist of a driver and passenger side.
NOTE: Wrangler sport models must have factory step pad removed for installation.
3. Attach side bar to brackets using 1/2" x 2" hex head fasteners as shown. Leave loose.
4. Place threaded mount plates through underside of suspension so that the holes line up as shown. Attach brackets to mount plates using 1/2" x 1" hex head fasteners as shown. SEE FIGURE. Make sure side bar is properly aligned whit vehicle body.
5. Make any final adjustments to the alignment of the sidebar and tighten all bolts. Repeat for the opposite side.
6. You may need to periodically re-tighten the bolts.

Assembly Diagram:

FRONT SUSPENSION MOUNT



Cleaning and care instructions:

Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish, or wax that contains an abrasive is detrimental to the finish, as the compounds scratch the finish and cause corrosion.

Diseño:

Calidad:

Revised 10-07-06

G:\Usuarios\Diseño\Instructivos PDF\37s\37141-I.Pdf