## INSTALLATION INSTRUCTIONS FOR DYNOMAX KIT: 39506 2014-11 Ford F250, F350 Super Duty, Gas Eng., 2 / 4 WD



2701 N. Dettman Rd. Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS OR SCISSOR JACK ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

## NOTE: Read all instructions before starting any work.

- 1. Remove the O.E. inlet pipe/muffler/tail pipe welded assembly from the vehicle. Lubricate the rubber isolators with WD-40, or similar product, to aid in removal of the muffler metal rod hangers.
- 2. Install DynoMax Y-pipe **54739**. Reuse the O.E. band clamp on the front RH exhaust leg.
- 3. Depending on the wheelbase length of your truck, use the appropriate extension pipe as indicated: Please see system diagram.
  - a. Reg cab, 8' bed 137" WB no pipe required.
  - b. Super cab, 63/41 bed 141.811 WB use **51073** ext. pipe.
  - c. Crew cab, 63/41 bed 156.211 WB use **52481** ext. pipe.
  - d. Crew cab, 8' bed 158" WB use **52481** ext. pipe.
  - e. Crew cab, 8' bed 172.4" WB use  $\bf 52481$  and  $\bf 52482$  ext. pipes.
- 4. Slip clamp-on rod hanger **36409** over the inlet end and install DynoMax Ultra Flo Welded muffler **17557**. Do not tighten the band clamp at this time.

- 5. Slip a band clamp over the inlet end and install DynoMax tail pipe **55569**. Insert the metal rod hangers into the three (3) rubber isolators on the chassis and frame.
- 6. Install DynoMax SS tip 36477 using the supplied band clamp.
- 7. Beginning at the inlet end, align system and tighten all the clamps.
- 8. Please see the system diagram on the back page of these instructions.

## KIT CONTAINS:

- (1) 17557 MUFFLER
- (1) 54739 Y-PIPE
- (1) 51073 EXT. PIPE
- (1) 52482 EXT. PIPE
- (1) 52481 EXT. PIPE
- (1) 55569 TAIL PIPE
- (1) 36477 SS TIP
- (1) 36409 CLAMP-ON ROD HANGER
- (4) 4" BAND CLAMP
- (1) 711098 INSTRUCTION SHEET

Form: 711098 Revised 01/14

## 39506 SYSTEM DIAGRAM 36477 4" Clamp 36409 4" Clamp 55569 51073 54739 17557 4" Clamp 52482 Clamp 52481 Form: 711098 Revised 01/14