

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX SUPER TURBO MUFFLER KIT: 39510**
2014-12 Jeep Wrangler, Wrangler Unlimited 3.6L
2011-07 Jeep Wrangler, Wrangler Unlimited 3.8L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME. BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS OR SCISSOR JACK ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the O.E. muffler assembly from behind the O.E. intermediate pipe. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install the DynoMax Super Turbo SS muffler assembly **53804**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the OE intermediate pipe.

3. Install DynoMax SS tips **36484**. See the system diagram on the back page of these instructions.
4. Beginning at the inlet end, align the muffler assembly and tighten all clamps.

KIT CONTAINS:

- (1) 53804 MUFFLER ASSEMBLY
- (2) 36486 SS TIPS w/2½" CLAMPS
- (1) 36438 2½" BAND CLAMP
- (1) 711990 INSTRUCTION SHEET

39510 SYSTEM DIAGRAM

