

**INSTALLATION INSTRUCTIONS FOR  
DYNOMAX SUPER TURBO MUFFLER KIT: 39525**  
2014-11 Chrysler 300 / Dodge Charger w/3.6L Eng.  
w/Factory Dual Exhaust



2701 N. Dettman Rd.  
Jackson, MI 49201

**DANGER WARNING:** SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

**NOTE:** Read all instructions before starting any work.

1. Remove the O.E. system assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust X-Pipe **54812**. Slightly tighten the inlet 2¼" clamps on the inlet end.
3. Install DynoMax Super Turbo mufflers **17629**, RH & LH. Slightly tighten the 2½" clamps that connect the mufflers to the x-pipe.
4. Install RH tail pipe **55591** and LH tail pipe **55592**. Insert the metal rod hangers into the rubber insulators on the chassis. Use 2½" clamps to connect the tail pipes to the muffler outlets.

5. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
6. Please see the system diagram on the back page of these instructions.

**KIT CONTAINS:**

- (2) 17629 MUFFLERS
- (1) 54812 FRONT X-PIPE
- (1) 55591 RH TAIL PIPE
- (1) 55592 LH TAIL PIPE
- (2) 2¼" BAND CLAMPS
- (4) 2½" BAND CLAMPS
- (1) 713102 INSTRUCTION SHEET

# 39525 SYSTEM DIAGRAM

