

# Installation Instructions



Real Truck Bed Protection System®

**DODGE RAM  
2002 – 2008  
DOFPAK1**

\*Requires a Phillips screwdriver and both a T30  
& T40 Torx bit (with bolt in tie downs)

**NOT INCLUDED**

Please read all instructions before beginning the installation process.

Install videos available at [DualLiner.com/dualliner-videos](http://DualLiner.com/dualliner-videos)

While temperature does not affect your DualLiner, it is easier to install when the bedliner is above 50 degrees Fahrenheit. If working in colder temperatures, it is helpful to warm the bedliner indoors prior to installation. The mat may take a "set" while rolled. If possible, unroll the mat and let it "relax" in the sun to make it easier to work with. If installing in cold weather it may take several weeks for the mat to fully relax.

## **IMPORTANT - Truck Bed Preparation:**

- If you have bolted in tie downs, you must remove the tie downs using a T40 Torx Driver.
- If you have welded in tie downs, the side walls will fit over them and they do not need to be removed.

## **Step 1: Install the loadguard panel. (Fig. 1)**

- Snap the panel over the top rail and behind the factory tie down locations in the front of the truck.

## **Step 2: Install the sidewall panels. (Fig. 2)**

- Align the top edge of the side wall panel underneath the rail.
- \*If your truck has rail caps, tuck the ends of the side wall behind the rail caps.
- Connect the side wall to the loadguard using the provided pine tree pins.

\*Use a Phillips head screwdriver as an alignment tool if needed.

- Reattach bolted tie downs using a Phillips head to align the holes.

\*Insert the tie down screws, leaving them loose until all 4 are started, then tighten.

- Repeat on the other side.

## **Step 3: Install the ZeroSkid Rubber Floor®. (Fig. 3)**

- Lift the mat into the truck and unroll with nub side down.
- Start tucking the mat into the channel from front to back.
- \*Tip: It is generally easiest to tuck one side, then the other side.
- Make sure it is pulled as far forward as possible for best fit.
- The mat will "settle" into position, sometimes giving it a kick or shuffling your feet will help it find its place.

## **Step 4: Install the tailgate panel. (Fig. 4)**

- Remove 8 of the 10 the access latch panel screws using a T30 Torx Driver. Leave the top 2 center latch screws in place. The tailgate panel will overlap the tailgate cap a bit for the holes to line up properly for installation.
- Place a nylon spacer on each screw and reinstall.

\*Optional: Drill 1/4" holes in the center of each slot of the panel. Lift up the panel and clear any drill chips away. Apply some of the rust preventative gel to both the holes and the pine tree pins. Insert one pin in each hole, twisting as you press in place to evenly distribute the gel. Do not over-tighten, and do not use power tools. We have also included double-sided tape, should you choose not to drill. (See insert)

That's it! Now your truck and your cargo are protected for a LifeTime!

Don't forget to visit [DualLiner.com](http://DualLiner.com) to register your Real LifeTime Warranty!



Fig. 1



Fig. 2



Fig. 3



Fig. 4

Have Questions? Contact Customer Service:

Phone: 800-992-1949, Email: [CustomerService@DualLiner.com](mailto:CustomerService@DualLiner.com),  
or Chat with us at [DualLiner.com](http://DualLiner.com)



**Real** Truck Bed Protection System®

DualLiner, LLC  
143 S. Main St, 2nd Floor  
West Bend, WI 53095  
800-992-1949 Tel.  
CustomerService@DualLiner.com

## **Real Lifetime Warranty**

Thank you for selecting DualLiner, The Only Bedliner That Works®! You have chosen the best way to protect your truck and cargo.

DualLiner warrants the performance of the bedliner components for their life. The LifeTime Warranty must be registered with DualLiner, LLC within 30 days of purchase. Original owners can also provide Proof of Purchase under same ownership for Warranty verification. The bedliner is transferable to a new truck or owner, transfers of warranty must be re-registered through DualLiner within 5 business days of transfer. Failures due to improper installation, uninstall or reinstall are not covered. DualLiner reserves all rights and privileges with regard to warranty determination. Please contact DualLiner at 800-992-1949 for any warranty questions.

Limited liability:

The foregoing remedy of component replacement is at the manufacturer's discretion and is the buyer's sole remedy. Manufactured components are subject to variance. Both polyethylene and rubber components are affected by heat, cold, sun and other environmental factors. Due to these tolerances it is important to note that manufactured parts may shift and change depending on environmental factors for the life of the product. See Terms & Conditions for further definition.

This warranty is in lieu of any other warranty, expressed or implied. It includes replacement of the failed component. It does not include installation labor, nor does it cover any consequential damages caused by loss of use of the vehicle or failure of the component. Manufacturer's maximum liability under this agreement shall not, in any case, exceed the price of the product claimed to be defective. There are no warranties of merchantability or fitness for a particular purpose.

Please go to [www.DualLiner.com](http://www.DualLiner.com) for warranty registration.

*DualLiner Real LifeTime Warranty, Revised June 2017  
Supersedes prior Warranty Document*

### **INSTALLATION PARTS LIST**

#### **DODGE RAM 2002-2008:**

(DOFPAK1)

16 Pine-Tree (push pins)

8 Nylon Spacers

1 Rust Inhibitor Gel Pack

4 Strips Double Sided Tape (please see insert for usage)

1 Alcohol Wipe