



Installation Instructions

Stainless Axle-Back Exhaust System
Dodge Durango 5.7L Awd

Part #616006



ITEM	PART	QUANTITY	DESCRIPTION
A	701172S	1	2.25" Stainless Driver Side Muffler Assembly
B	701173S	1	2.25" Stainless Passenger Side Muffler Assembly
C	5756	2	2.25" Clamp

Thank you for purchasing our Gibson Exhaust System for your vehicle.
If you need further assistance, please do not hesitate to call our technical department at
(800) 528 -3044 Monday through Friday, 8am to 5 pm.

Installation Instructions #616006

When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 1/2", 9/16", 15mm wrenches & sockets, WD-40, hacksaw, jack stands

1. Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.



2. To remove your stock exhaust:
Drivers Side: measure 9" down the pipe from the back of the muffler. You will be removing the factory hanger.



3. Next install your driver and passenger side muffler assembly's. Insert welded hangers into rubber grommets adjust assembly's. Use clamps #C to secure



Passenger side: measure 12" down the pipe from the back of the muffler.

