



X-ACT CONTOUR FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 54891

Thank you for selecting X-act Contour™ Floor Liners from Husky Liners. Your new second seat floor liner is custom molded to fit your specific vehicle's floor board. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO EASE INSTALLATION OF YOUR SECOND SEAT LINER, MOVE BOTH FRONT ROW SEATS COMPLETELY FORWARD. WITH THIS DONE, INSTALL YOUR LINER, POSITIONING IT AS SHOWN IN THE IMAGE ABOVE. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED AND LOWER YOUR 2ND ROW SEATS.