



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN: 54921

Thank you for selecting X-act Contour™ Front Floor Liners from Husky Liners Inc. Your **new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER

TO INSTALL YOUR LINERS, MOVE THE FRONT SEATS COMPLETELY BACK TO EXPOSE THE FRONT FLOOR PANS. WITH THIS DONE, POSITION THE LINERS IN THE FLOOR PANS AS SHOWN ABOVE. THE **DRIVER'S** SIDE LINER ATTACHES TO THE FACTORY FLOOR MAT HOOK.