

IAG Street, Comp, Race Engine Mount Set w/ Brackets for 15-21 WRX



Step 1/11


IAG-DRV-20XX - IAG Street, Comp, Race FA Engine Mount Set w/ Brackets for 2015-21 WRX

Part# IAG-DRV-2006, IAG-DRV-2016, IAG-DRV-2026

Tools Required: Ratchet, Torque Wrench

Sockets: 14mm


Congratulations on the purchase of your IAG engine mount set, and thank you for choosing IAG Performance. This installation manual is intended to guide you through the installation of the IAG Engine Mounts. This guide applies to Street, Comp, and Race series mounts. This installation assumes that you are familiar with the removal of the OEM engine mounts. If you are not familiar with this procedure please consult the factory service manual for your vehicle. If you do not own the factory service manual you may purchase temporary access at https://techinfo.subaru.com/stis/#/purchase_subscription to aid in your installation. Professional installation of this product is recommended.



Step 2/11

Numbered annotations (1)


- 1 Remove the OEM engine mounts per the factory service manual.



Step 3/11

Numbered annotations (1)


- 2 Save the OEM engine mount bolts closest to the firewall - these will be reused to install the IAG mounts.



Step 4/11

Numbered annotations (1)

- 3 Use this bolt in the next step.



Step 5/11


Numbered annotations (1)

- 4 Locate the included engine mount spacer.

Step 6/11

Numbered annotations (1)


- 5 Install the OEM engine mount bolt into the new IAG mount. The included spacer will fit between the mount and the block.




Step 7/11

Numbered annotations (1)

- 6 OEM bolt and included IAG spacer installed on new engine mount.






Step 8/11

Numbered annotations (1)

- 7 Install the engine mount with the included spacer. Hand tighten both engine mount bolts to the block.




Step 9/11

Numbered annotations (1)

- 8 Repeat the previous steps and install the second engine mount in the same manner.



Step 10/11



Step 11/11

Numbered annotations (2)

- 9 Torque engine mount to cylinder block bolts to 35nm
- 10 After installation in the vehicle, torque these nuts to 45nm