

CRAWLTEK R E V O L U T I O N

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

PYRO ROCKER GUARDS

JK41101 - 2 DOOR

FOR USE WITH ALL
JK AND JKU MODELS FROM 2007-2018



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2020-11-24

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
06071	1	JK 2 DOOR ROCKER GUARD - DRIVER
06072	1	JK 2 DOOR ROCKER GUARD - PASSENGER
06073	1	JK 2 DOOR OUTER PANEL - DRIVER
06074	1	JK 2 DOOR OUTER PANEL - PASSENGER
CWLU30010	1	DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5"
CWLU30020	1	DECAL: CRAWLTEK EYES 6" X 2"
CWLU30030	1	DECAL: CRAWLTEK JAX 3.75" X 2.8"
	34	5/16"-18 X 1" BLACK STAINLESS STEEL FLAT SOCKET CAP SCREW
	20	5/16"-18 PANEL RANGE:.025"-.150" CENTER 9/16" EXTRUDED U NUT
	14	5/16"-18 ZINC SERRATED HEX FLANGE NUT
	8	M6-1.0 X 25MM CLASS 10.9 YELLOW ZINC FINISH HEX CAP SCREW
	8	M6 X 12MM OD YELLOW ZINC GENERAL PURPOSE FLAT WASHER
	8	M6-1.0 FREE SPINNING WASHER NUT 19MM OD YELLOW ZINC

TOOLS REQUIRED

SAFETY GLASSES

18MM SOCKET OR WRENCH

10MM WRENCH OR SOCKET

1/2" SOCKET OR WRENCH

5/8" SOCKET OR WRENCH

ANTI SIEZE

SMALL HAMMER

FACTORY ROCK RAIL REMOVAL (IF EQUIPPED)

STEP 1:

REMOVE (X) BOLTS UNDER EACH SIDE OF THE VEHICLE.

STEP 2:

REMOVE (4) NUTS ALONG EACH PINCH SEAM.

STEP 3:

REMOVE OEM ROCK RAILS.



INSTALLATION OF ROCK LIGHTS (OPTIONAL)

STEP 3:

IF INSTALLING OPTIONAL LIGHTS INSTALL NOW. USING HARDWARE SUPPLIED BY LIGHT MANUFACTURER, INSTALL THE LIGHTS BEHIND THE ROCKER GUARD.

INSTALLATION OF THE ROCKER GUARDS

STEP 4:

REMOVE BODY MOUNT BOLTS (2).

STEP 5:

USING ORIGINAL BODY MOUNT BOLTS SET ROCKER GUARD FRAME IN PLACE, DO NOT TIGHTEN.

STEP 6:

USING THE SUPPLIED M6 HARDWARE ATTACH ROCKER TO THE OUTSIDE OF THE PINCH SEAM.

STEP 7:

RUN WIRING FOR ROCK LIGHTS AND CONNECT TO SWITCH.

STEP 8:

TIGHTEN ALL BOLTS FOR ROCKER GUARD FRAME.

STEP 9:

INSTALL U-NUTS IN TO ROCKER GUARD FRAME.

STEP 10:

INSTALL OUTER ROCKER GUARD PANEL WITH 5/16 HARDWARE.

STEP 11:

REPEAT ON OPPOSITE SIDE.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

Be sure to show off your jeep to the rest of the CrawlTek Revolution online. Find us on facebook and instagram to keep up on new products, upcoming events and more action. Tag us @crawltek for a chance to get featured

