

SPECTRE®

Performance

Throttle Body Spacer Installation Instructions P/N 11255

1992-2002	Dodge Ram 1500	3.9L V6, 5.2L V8, 5.9L V8
1992-2002	Dodge Ram 2500	5.2L V8, 5.9L V8
1992-2002	Dodge Ram 3500	5.9L V8

PARTS FOR VEHICLES LISTED ARE 50 STATE LEGAL.
SEE SPECTREPERFORMANCE.COM FOR CARB
STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

Parts List

- 1 - Spectre Power Plate
- 4 - 5/16"-18 x 3 3/16" hex bolts
- 4 - 5/16" flat washers
- 2 - Gaskets



Step 1
Disconnect the negative battery cable.

Step 2
Remove the air cleaner assembly.

Step 3
Remove the four 1/2" bolts which secure the throttle body to the intake manifold.

Step 4
Remove the two bolts securing the throttle cable bracket to the intake manifold. Place these aside for later use.

Step 5
Move the throttle body forward and clean both gasket surfaces.

Step 6
Using the supplied bolts, washers, and gaskets, install the Spectre Power Plate. Make sure that the surface marked "11255" is facing the throttle body. Place one gasket between the intake manifold and the Power Plate, and the other between the Power Plate and the throttle body.

Step 7
Ensure that the throttle operates freely and that the blade doesn't make contact with the Power Plate before fully tightening the bolts. Torque the bolts to factory specifications – Do Not Over-Tighten.

Legal for use on pollution
controlled vehicles
C.A.R.B E.O.# D-629-5
for applications listed above

Step 8

Check the throttle lever for full travel. If adjustments to the throttle cable, kickdown cable, or cruise control cable are necessary, consult the factory service manual.

Step 9

Reinstall the air cleaner assembly.

Step 10

Install the C.A.R.B. exemption label near the factory emissions label.

Step 11

Reconnect the negative battery cable.

Step 12

Start the engine and let the vehicle warm up. Shut the vehicle off and recheck your installation, making sure that all bolts and hose clamps are fully tightened.

If you have any difficulties or questions regarding the installation of this Throttle Body Spacer, contact the Spectre Performance Technical Department by email- Tech@spectreperformance.com or by phone 1-800-821-4868 Monday thru Thursday 6:00am to 4:30pm PST.

PARTS FOR VEHICLES LISTED ARE 50 STATE LEGAL.
SEE SPECTREPERFORMANCE.COM FOR CARB
STATUS ON EACH PART FOR A SPECIFIC VEHICLE.

SPECTRE
Performance

(909) 673-9800

www.spectreperformance.com

© 2014 SPECTRE PERFORMANCE Made in China

176193A
9/12/14