

## OBD Splice cable 2018 Chrysler products

### 2018 Jeep srt/trackhawk

- Can bus junction block is in the passenger footwell area, to the left of the glove box. See first picture.
- Pull back carpet on the left side and there will be a green junction box. Plug the small white connector on the cable to one of the open ports.
- Run the obd connectors back to the driver's side and connect to the vehicle port.
- Use the new obd port for tuning/diagnostics.
- This cable can be left running on top of the dash/center console loosely if this is a temporary install. If permanent route the wires behind the dash and zip tie/secure cables out of the way.

### 2018 + Charger/Challenger

- Can bus junction block is in the passenger footwell area, directly below the glove box on the right side. See second picture.
- Remove the lower trim panel right behind/below the glove box, there will be 3 push pins and a small electrical connector.
- The junction box is located right behind glove box, on the right side. Connect the small white plug into one of the open ports on the junction.
- Run the obd connectors back to the driver's side and connect to the vehicle port.
- Use the new obd port for tuning/diagnostics.

-This cable can be left running on top of the dash/center console loosely if this is a temporary install. If permanent route the wires behind the dash and zip tie/secure cables out of the way.

Picture 1 (Jeep srt/trackhawk location)



Picture 2 (challenger/charger location)

