If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS BY





THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR NP92-18/ Oe32-18 / SL62-18/ SP82-18/ TR42-18/ TRS42-18

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

A) BACKREST COVER


- 1) Starting with the top left corner of the seat, install cover by attaching velcro to carpeting on back of seat
- 2) Smooth cover tightly from top to bottom
- 3) Tuck stretch fabric at bottom of cover through crevice and behind backrest. For easier access raise seat cushion and hold in 3/4 up position
- 4) Smooth cover tightly on both sides and attach velcro on to carpeting
- 5) Tuck stretch fabric around top and sides of seat to cover up the velcro

B) CUSHION COVERS

- 1) Center cover on seat
- 2) While holding cushion in 3/4 up position, tuck back flap through crevice
- 3) Pass the front strap under cushion and buckle to back flap
- 4) Pass side straps around the back of seat and buckle
- 5) Adjust straps and buckles to equalize tension

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

5-26-11