If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS BY

fia



FEATURING SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR NP92-51/ Oe32-51/ SL62-51/ SP82-51/ TR42-51/ TRS42-51

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

CUSHION COVERS:

INSTRUCTIONS:

- 1. Center cover on seat
- 2. Lift cushion halfway up
- 3. Insert straps through crevice and buckle
- B) BACKREST COVER 40 PORTION:
 - 5. Smooth cover tightly from top to bottom
 - 6. Insert flaps through crevice and attach to velcro at back

4. Attach velcro to carpet on underside of cushion5. Adjust all straps, buckles and velcro to equalize tension

7. Re-install headrest (see NOTES)

- 1. Remove headrests (see NOTES)
- 2. Unlatch backrest from the back wall
- 3. Slip cover over backrest
- 4. Place side latch through opening provided

C) BACKREST COVER - 60 PORTION:

1. Repeat steps 1 – 7 from section B) above

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



3)) RE-INSTALLATION OF HEADRESTS:

- Locate headrest base and put a small hole in the fabric to accommodate each of the posts
- Replace headrests

2) HEAD REST REMOVAL:

- A) Insert paper clip into holes at base to release
 - Lift off

<u>OR</u>

- B) Push in side release buttons
 - Lift off
- (If unable to remove consult dealership)



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com