

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com


SEAT COVERS
BY

fia

FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM



INSTALLATION INSTRUCTIONS
FOR
OE32-96/ SL62-96/ SP82-96/ TR42-96

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) BACKREST COVER 40 side:

- | | |
|--------------------------------------|---|
| 1) Unlatch backrest from back wall | 4) Tuck flaps through crevice under backrest |
| 2) Remove headrests (see note below) | 5) Fold down backrest and attach flaps on velcro at back of cover |
| 3) Slip cover over backrest | 6) Replace headrests (see notes) |

B) BACKREST COVER 60 side:

- | | |
|--|---|
| 1) Unlatch backrest from back wall | 4) Tuck flaps through crevice under backrest |
| 2) Remove headrests (see note below) | 5) Fold down backrest and attach flaps on velcro at back of cover |
| 3) Slip cover over backrest under center seat belt | 6) Replace headrests (see notes) |

C) CUSHION COVERS 40 side:


- | | |
|---|--|
| 1) Center cover on seat | 5) Pass the straps under seat and buckle |
| 2) Tuck back flap into crevice | 6) Apply velcro to underside of cushion |
| 3) Ensure the slit is in line with car seat hook up | 7) Adjust straps and buckles to equalize tension and ensure a snug fit |
| 4) Lift seat in up position | |

D) CUSHION COVER 60 SIDE:

- | | |
|--|--|
| 1) Center cover on the seat. Cover has opening with velcro for seat belt buckle (see note below) | 4) Apply velcro to underside of cushion |
| 2) Tuck back flap through crevice | 5) Adjust straps and buckles to equalize tension and ensure a snug fit |
| 3) Lift seat and pass the straps under seat and buckle | |

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

- Push in side release buttons
- Lift off
- (If unable to remove consult dealership)



3) ADHESIVE BACK VELCRO:

Before positioning velcro, clean area with alcohol swab provided.

4) SEAT BELT OPENING

- Detach velcro pieces.
- Slide cover under seat belt base
- Re-attach velcro around seat belt base

5) RE-INSTALLATION OF HEADRESTS

- Ensure pre-cut holes in seat cover align with holes in headrest base.
- Replace headrests

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com