If you have any comments or concerns, please feel free to contact our customer service department at: Toll-free: 1-800-835-0438 OR Email: info@gofia.com SEAT COVERS

FEATURING



SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS

FOR

NP92-99 / OE32-99 / SL62-99 / SP82-99 / TR42-99 / TRS42-99

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

- 1) Remove headrests (see note)
- 2) Release velcro attached at bottom of backrest cover.
- 3) Release velcro on the side seam to allow for fitting around armrest
- 4) Slip cover over backrest and pull down firmly
- A) <u>BACKREST COVER</u> 5) Fasten side velcro
 - 6) Fold down backrest. Tuck cover through crevice and
 - attached to velcro at back
 - 7) Adjust all velcro to equalize tension
 - 8) Replace headrests (see note)

B) CUSHION COVER

- 1) Center cushion cover on seat. Cover has allowances
- for seat belt buckles and child restraint anchors
- 2) Pass front center strap through opening on hinge

between seat cushion and base

3) Lift cushion up in vertical position

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:




- 4) Pull front straps under cushion and buckle to back of cover
- 5) Pull side straps under cushion and buckle to other side
- 6) Adjust straps and buckle to equalize tension

3) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in base.
- B) Replace headrests

2) HEAD REST REMOVAL:

Push in side release buttons - Lift off (If unable to remove consult dealership)



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

tria