



IAG Fuel Rails with OEM FPR & FPR Adapter IAG-AFD-2002 Diagram

Applies for Part# IAG-AFD-2101, IAG-AFD-2200, IAG-ENG-2002

Diagram Key

1. FPR
2. Fuel Rail
3. -6 to -8 Reducer Fitting
4. Fuel Hose
5. Hose Barb T Fitting
6. -6 90° Fitting
7. Pinch Clamp
8. Fuel Quick Connect Fitting
9. FPR Adapter

