

COLD-GOLD SHIELD™

Product Installation Sheet



REV 05.20

Tools Required

- Safety glasses, dust mask, and gloves
- Heavy-duty scissors or utility knife
- Poster board or butcher paper
- Brake cleaner or other degreaser
- Pre-paint cleaner, isopropyl alcohol or other non-residue cleaner

WANT-TO-BE-FEATURED?

FOLLOW, POST, TAG:

@HEATSHIELDPRODUCTS

#RACETESTED



Installation Tips

Always wear safety glasses, dust mask and gloves when working with Cold-Gold™ Shield.

Use poster board or butcher paper to make a template. For surfaces with severe bends, it may be necessary to cut relief lines, wedges, or "pizza slices" to get product to conform. Test fit your template, if you are satisfied with the pattern, transfer template to Cold-Gold™ Shield.

This product is electrically conductive, be sure to insulate any terminals or circuits that may come in contact with this product.

Installation Steps

1. Put on PPP - gloves, safety glasses, and dust mask
2. Panel or component surface temperature should be at least 65°F, sticking onto anything colder may not allow adhesive to set up properly.
3. Degrease and clean surface of any residual chemicals, using carburetor spray or other cleaner/degreaser.
4. Rub the surface with a pre-paint cleaner or isopropyl alcohol (or other non-residue cleaner) after cleaning and degreasing.
5. Carefully peel the adhesive backing off the Cold-Gold™ Shield. Start peeling from one corner.
6. Lay the Cold-Gold™ Shield, start on one edge of panel or component and work out slowly to ensure no "bubbles" occur. Air bubbles will cause the material to not stick and fall off.
7. Press the Cold-Gold™ Shield firmly onto the panel/component, hold while pressing down for 30 seconds.
8. Let Cold-Gold Shield set up for 2 hours before you subject it to any heat.
9. Clean up and have fun!

HEATSHIELD PRODUCTS, INC.

Escondido, CA

© Heatshield Products, Inc.

AMERICAN
MADE SINCE 1985



(760) 751-0441

tech@heatshieldproducts.com

www.heatshieldproducts.com